

at eyedro.com Full warranty policy details are available

manufacturer, during this period. repaired or replaced, at the discretion of the workmanship. Defective parts may be of purchase for all defects in material and product for a period of one year from date Eyedro Green Solutions Inc. warrants this

where electrified areas within the panel are. Mod attempt installation unless you know should be performed by a qualified electrician. of shock, burn, and electrocution. Installation panel may still be dangerous and carry the risk has been turned 'OFF' certain areas of the are still electrified. Even when the main breaker electrical panel to be removed while some wires Installation may require the cover of the main



located at eyedro.com/support and video can be found in the Product Manual instructions. Complete installation instructions This insert provides very high level installation

Before Getting Started





Visit **eyedro.com** for any questions or comments. We value your feedback.



Quick Start Guide

Wireless Electricity Monitoring System (EBWEM1)

1. Verify Package Contents



	QTY	DESCRIPTION	
А	1	Eyedro Gateway Module	
A	1	Eyedro Sensor Module	
В	3	Current Sensors (200A to 5000A max 600VAC)	
С	2	Low-voltage Power Adapter	
D	1	3ft (0.9m) Ethernet Cable	

2. Record Serial Numbers

Gateway SN:	-	
Sensor SN:	-	

4. Create a MyEyedro User Account

4.1 GO ONLINE TO: my.eyedro.com to create your online account (or login if you have an existing account).




- 4.2 Add the devices to your user account by entering the serial numbers recorded earlier.
- 4.3 ENJOY! Login to MyEyedro as often as you like to view your electricity consumption.
- 4.4 For more details regarding the MyEyedro service, review the MyEyedro User Guide located at eyedro.com/support.


3. Install Hardware

- 3.1 IInstall Current Sensor(s) on the line1 conductor of the circuit(s) to be monitored.
 - ¹Line/Live/Hot conductor(s) only



- 3.2 Securely mount the Eyedro modules, using the template provided below (optional).
- 3.3 Connect Sensor(s) and power adapter to the Sensor module.
 - 3.4 Connect Ethernet and power adapter to the Gateway module.





Template for mounting the **Eyedro Modules (optional)**

Cut out the below template and use it as a guide to mark screw locations for a wall mounted module.

