



Full warranty policy details are available at eyedro.com

Eyedro Green Solutions Inc. warrants this product for a period of one year from date of purchase for all defects in material and workmanship. Defective parts may be repaired or replaced, at the discretion of the manufacturer, during this period.

Limited One Year Warranty



Visit eyedro.com for any questions or comments. We value your feedback.

This insert provides very high level installation instructions. Complete installation instructions and video can be found in the Product Manual located at eyedro.com/support

Installation may require the cover of the main electrical panel to be removed while some wires are still electrified. Even when the main breaker has been turned 'OFF' certain areas of the panel may still be dangerous and carry the risk of shock, burn, and electrocution. Installation should be performed by a qualified electrician. DO NOT attempt installation unless you know where electrified areas within the panel are.



Before Getting Started




Quick Start Guide

Wireless Electricity Monitoring System (EHWEM1)

For applications not exceeding
200A up to 300VAC

1. Verify Package Contents



| | QTY | DESCRIPTION |
|---|-----|---------------------------------------|
| A | 1 | Eyedro Gateway Module |
| | 1 | Eyedro Sensor Module (2 sensor ports) |
| B | 2 | 200A Current Sensors |
| C | 2 | Low-voltage Power Adapter |
| D | 1 | 3ft (0.9m) Ethernet Cable |

2. Record Serial Numbers

Gateway SN: -

Sensor SN: -

4. Create a MyEyedro User Account

4.1 GO ONLINE TO: my.eyedro.com to create your online account (or login if you have an existing account).

4.2 Add the devices to your user account by entering the serial numbers recorded earlier.

4.3 ENJOY! Login to MyEyedro as often as you like to view your electricity consumption.

4.4 For more details regarding the MyEyedro service, review the MyEyedro User Guide located at eyedro.com/support.

3. Install Hardware

3.1 Install Current Sensor(s) on the **line**¹ conductor of the circuit(s) to be monitored.



¹Line/Live/Hot conductor(s) only



3.2 Securely mount the Eyedro modules, using the template provided below (optional).

3.3 Connect Sensor(s) and power adapter to the Sensor module.

3.4 Connect Ethernet and power adapter to the Gateway module.



Template for mounting the Eyedro Modules (optional)

Cut out the below template and use it as a guide to mark screw locations for a wall mounted module.

