



## **Quick Start**

# **Electricity Monitoring System (includes Gateway) with Wireless Mesh connectivity**

## **EB-M-GWE3(-SUB)**

For applications not exceeding 600Vac

### **Before Getting Started**

This Quick Start provides high level installation instructions. Visit [eyedro.com/support](http://eyedro.com/support) for complete product setup guide, warranty information, user manuals, videos, and various online support resources.



Installation may require the cover of the main electrical panel to be removed while some wires are still electrified. Even when the main breaker has been turned 'OFF' certain areas of the panel may still be dangerous and carry the risk of shock, burn, and electrocution. Installation should be performed by a qualified electrician. **DO NOT attempt installation unless you know where electrified areas within the panel are.**

**This product is intended for indoor use only.  
This product contains no user serviceable components.**

## 1. Record Device Serial Numbers (located on module label)


Gateway SN:	___ - ___ - ___ - ___ - ___ - ___ - ___
Sensor SN:	___ - ___ - ___ - ___ - ___ - ___ - ___

## 2. Install Hardware


- i. Install current sensors on the **line**(/live/hot) conductor of the circuit(s) to be monitored.



- ii. Connect an Ethernet cable between the Eyedro gateway module and an available port on your network equipment.
- iii. Connect power adapter to the Eyedro gateway module.



- iv. Connect sensors and power adapter to the Eyedro module.  
*Note: Sensor port C is only available on 3 sensor models*



## 3. Add Devices to your MyEyedro User Account

- i. Go to **my.eyedro.com** to create your online account (or log in if you have an existing account).
- ii. Add the devices using the Device Configuration page. You will need the serial numbers you recorded in Step 1.